



FUNCTIONAL ARMCHAIR WITH HIGH BACK

FREJA 237

Freja is a versatile furniture family with armchairs, sofas and chairs with different functions and sizes with tactile materials that create a varied but harmonious and uniform expression.

Freja 237 is a functional armchair in birch wood with wheels and footrest. It is stepless and adjustable, for increased functionality and accessibility. With adjustability controls on both sides of the armchair, it is easy to use and adjust as needed. The seat and back have removable upholstery for easy washing. Freja 237 is therefore a good choice for nursing homes and care homes. Freja 237 is tested for 160 kg user weight according to Möbelfakta's requirements.

Möbelfamiljen är tillverkad i FSC®-Mix och är märkt med Möbelfakta. Freja är ritad av NC Design Studio.

DIMENSIONS

Height	112 cm
Width	69 cm
Seat height	48 cm
Seat depth	50 cm
Höjd armledare	61 cm



Any color available as an option on this product.

CERTIFICATIONS



VIEWS



ADDED VALUE

- Possibility of adjustment controls on both sides of the armchair
- Back and seat designed for high comfort and stability
- Gap between seat and back for best hygiene
- Wheel
- Footrest
- Removable upholstery
- Any color
- Tested for public use and meets the requirements for durability & safety, set forth in the following standard, EN 16139
- Tested for 160kg

ACCESSORIES

- Frame in birch
- Frame in any color
- Rubber fabric/hospital fabric
- Adjustable neck pillow

NC Nordic Care AB

Box 30 573 35 Tranås Sweden

+46(0)140-38 40 60, info@ncnordiccare.se

ncnordiccare.se



- Fabric-covered armrests

REUSE

- Solid wood
- Removable upholstery

NC Nordic Care AB

Box 30 573 35 Tranås Sweden

+46(0)140-38 40 60, info@ncnordiccare.se

ncnordiccare.se



PLASTIC

For wiping, use a mild detergent without solvents or abrasives. Regular dish soap works well.

FABRIC

- Removable and washable fabrics are washed according to washing instructions. These are sewn with a shrink seam, wash before use for optimal fit.
- Vacuuming with a soft nozzle is often sufficient for cleaning.
- Stains should always be removed as quickly as possible. In most cases, wiping with a damp cloth is sufficient, for more difficult stains, a pH-neutral detergent or a foam detergent for professional use can be used.
- Always use white cloths and avoid wetting a woolen fabric to a greater extent, as this risks remaining stains.
- If necessary, a foam detergent can also be used for a more thorough cleaning if this is allowed in the fabric's specification.

WOOD

Wood is a living material whose grain from the very beginning has a natural variation in pattern, color tone and luster. The wood is affected by, among other things, the season, heat and humidity. That wood is a living material means:

- Screws need to be re-tightened regularly, at least once a year.
- Solid table tops can naturally warp by up to 0.5%.
- Light from the sun and lighting can cause permanent color and light differences in the surface, so allow the entire wooden surface to be exposed to the same amount of light.

Out of concern for the environment, we paint a large part of our range with water-based surface treatments. This means:

- Spills of coffee and other liquids need to be wiped up immediately.
- For cleaning, hand washing detergent or pH-neutral detergents and lukewarm water are recommended. Wipe off with clean water and wipe dry. Do not use cleaning agents that are alkaline, aggressive, contain abrasives or solvents.
- For disinfection, non-alcohol-based agents are recommended, e.g. Virkon or DAX Alco Free. Alcohol-based agents must not be used.