

FUNCTIONAL ARMCHAIR

KARIN 215

Karin functional armchair is adjustable to enhance functionality and comfort, with control options on both sides for improved accessibility and ease of use. For optimal hygiene, the armchair features removable and washable upholstery for easy cleaning, rubber fabric as standard, and a gap between the seat and back that helps prevent dirt and bacteria from building up. Karin 215 is tested for a user weight of up to 160 kg in accordance with Möbelfakta requirements.

Karin is ideal for public spaces where accessibility and comfort are key, such as in care homes and healthcare environments.

The armchair is made of FSC®-certified birch. It is offered as standard in clear lacquer, white, or black, and is also available in any custom color on request.

Design: Sylve Stenqvist

DIMENSIONS

Height	112 cm
Width	72 cm
Seat height	46 cm
Seat depth	47 cm
Arm guide height	60 cm

Any color available as an option on this product.

CERTIFICATIONS

FSC www.fsc.org FSC® C010544 The mark of responsible forestry

VIEWS



ADDED VALUE

- Controls on both sides
- Rubber fabric/hospital fabric on seat (standard)
- Removable upholstery
- Tested for public use and meets the requirements for durability & safety, set forth in the following standard, EN 16139
- Tested for 160kg

ACCESSORIES

- Frame in clear lacquer, white or black (standard)
- Frame in any color (special)
- Choice of fabric
- Rubber fabric/hospital fabric on seat (standard)

NC Nordic Care AB
Box 30 573 35 Tranås Sweden
+46(0)140-38 40 60, info@ncnordiccare.se
ncnordiccare.se

REUSE

- Solid wood
- Removable upholstery

NC Nordic Care AB
Box 30 573 35 Tranås Sweden
+46(0)140-38 40 60, info@ncnordiccare.se
ncnordiccare.se

METAL

- For regular cleaning, use a lightly moistened cloth with a mild detergent without solvents or abrasives.
- For heavily soiled surfaces, a cloth moistened with alcohol can be used.
- Disinfection can be done with alcohol if the surface is dried afterwards.

FABRIC

- Removable and washable fabrics are washed according to washing instructions. These are sewn with a shrink seam, wash before use for optimal fit.
- Vacuuming with a soft nozzle is often sufficient for cleaning.
- Stains should always be removed as quickly as possible. In most cases, wiping with a damp cloth is sufficient, for more difficult stains, a pH-neutral detergent or a foam detergent for professional use can be used.
- Always use white cloths and avoid wetting a woolen fabric to a greater extent, as this risks remaining stains.
- If necessary, a foam detergent can also be used for a more thorough cleaning if this is allowed in the fabric's specification.

WOOD

Wood is a living material whose grain from the very beginning has a natural variation in pattern, color tone and luster. The wood is affected by, among other things, the season, heat and humidity. That wood is a living material means:

- Screws need to be re-tightened regularly, at least once a year.
- Solid table tops can naturally warp by up to 0.5%.
- Light from the sun and lighting can cause permanent color and light differences in the surface, so allow the entire wooden surface to be exposed to the same amount of light.

Out of concern for the environment, we paint a large part of our range with water-based surface treatments. This means:

- Spills of coffee and other liquids need to be wiped up immediately.
- For cleaning, hand washing detergent or pH-neutral detergents and lukewarm water are recommended. Wipe off with clean water and wipe dry. Do not use cleaning agents that are alkaline, aggressive, contain abrasives or solvents.
- For disinfection, non-alcohol-based agents are recommended, e.g. Virkon or DAX Alco Free. Alcohol-based agents must not be used.

NC Nordic Care AB
Box 30 573 35 Tranås Sweden
+46(0)140-38 40 60, info@ncnordiccare.se
ncnordiccare.se