



DIMENSIONS

Width 90 cm Length 180 cm



Any color available as an option on this product.

CERTIFICATIONS



VIEWS



ADJUSTABLE TABLE


NIVÅ 231

Nivå 231 is a rectangular table that can be raised and lowered. The table is available in birch and oak and stained in white or black as standard.

The Nivå series includes 9 different tables, with different lengths and shapes. Five of the tables are mechanically adjustable with crank.

The entire series is labeled with Möbelfakta and FSC mix.

Nivå är ritad av NC Design Studio.



ADDED VALUE

- Stylish and functional
- Mechanically adjustable height with the help of a crank, 72-83
- Rectangular dining room table
- The top board has a length of 180 cm
- Any color
- Tested for public use and meets the requirements for durability & safety, set forth in the following standard, EN 15372

ACCESSORIES

- Frame in birch or oak
- Frame in any color
- The top board is available in birch & oak veneer, birch & oak laminate and white laminate.
- Many color variants for the tabletop

REUSE

• Solid wood (leg stand)



LAMINATE

Laminates are very durable surfaces that fit well in public environments.

- Daily cleaning with a dry cloth.
- For more difficult stains, non-abrasive cleaners can be used.
- Hardly ingrained stains or discolorations can usually be removed by carefully using a cleaning agent with a mild abrasive action.
- Rings and streaks that form on the surface are most easily removed with window cleaner.
- Do not use scouring pads or steel wool as this will cause scratches.
- Marker and ink marks can be removed with e.g. acetone or alcohol on a clean cloth.
- Disinfection can be done with alcohol if the surface is dried afterwards.

METAL

- For regular cleaning, use a lightly moistened cloth with a mild detergent without solvents or abrasives.
- For heavily soiled surfaces, a cloth moistened with alcohol can be used.
- Disinfection can be done with alcohol if the surface is dried afterwards.

PLASTIC

For wiping, use a mild detergent without solvents or abrasives. Regular dish soap works well.

WOOD

Wood is a living material whose grain from the very beginning has a natural variation in pattern, color tone and luster. The wood is affected by, among other things, the season, heat and humidity. That wood is a living material means:

- Screws need to be re-tightened regularly, at least once a year.
- Solid table tops can naturally warp by up to 0.5%.
- Light from the sun and lighting can cause permanent color and light differences in the surface, so allow the entire wooden surface to be exposed to the same amount of light.

Out of concern for the environment, we paint a large part of our range with water-based surface treatments. This means:

• Spills of coffee and other liquids need to be wiped up immediately.



•	For cleaning, hand washing detergent or pH-neutral detergents and lukewarm water are recommended. Wipe off
	with clean water and wipe dry. Do not use cleaning agents that are alkaline, aggressive, contain abrasives or
	solvents.

• For disinfection, non-alcohol-based agents are recommended, e.g. Virkon or DAX Alco Free. Alcohol-based agents must not be used.