



ARMCHAIR WITH HIGH BACK

JACKIE 541

The furniture family Jackie's armchairs come in a stylish design, with many smart functions

The armchairs are available in different sizes for increased comfort and accessibility.

The armchair Jackie 541 has a high back and neck pillow, which makes it stable and comfortable. Jackie 541 has removable and washable upholstery. The frame is made of birch, which provides long durability and longevity.

Möbelfamiljen Jackie är tillverkad i FSC-certifierad björk och är märkt med Möbelfakta. Jackie är ritad av Peter Andersson.



DIMENSIONS

Height	117 cm
Width	69 cm
Depth	71 cm
Seat height	47 cm
Seat depth	46 cm
Höjd armledare	63 cm



Any NCS-color available as an option on this product.

CERTIFICATIONS



VIEWS



ADDED VALUE

- Uniform expression with multifunctions
- Customizable and generous seating
- Offers many tactile materials
- Gap between seat and back for best hygiene
- Easy to get to under the armchair, which facilitates cleaning
- Removable fabric
- Any NCS color
- Tested for 200kg

ACCESSORIES

- Low or high back
- +5 cm seat height
- Fabric-covered armrests
- Frame in any NCS color
- Rubber fabric/hospital fabric

NC Nordic Care AB

Box 30 573 35 Tranås Sweden
 +46(0)140-38 40 60, info@ncnordiccare.se
 ncnordiccare.se



RECYCLING

- Solid wood
- Removable upholstery
- Replaceable padding

NC Nordic Care AB

Box 30 573 35 Tranås Sweden

+46(0)140-38 40 60, info@ncnordiccare.se

ncnordiccare.se



LEATHER

If you take care of the leather in the right way, it will become more beautiful over the years.

- Leather is heat sensitive. Therefore, direct sunlight and close contact with heating elements should be avoided.
- Vacuum the furniture to remove loose dirt and dust.
- Wipe the leather with a slightly damp cloth and a mild soapy solution can be used for cleaning.
- Water-based leather care products extend the lifespan.

FABRIC

- Removable and washable fabrics are washed according to washing instructions. These are sewn with a shrink seam, wash before use for optimal fit.
- Vacuuming with a soft nozzle is often sufficient for cleaning.
- Stains should always be removed as quickly as possible. In most cases, wiping with a damp cloth is sufficient, for more difficult stains, a pH-neutral detergent or a foam detergent for professional use can be used.
- Always use white cloths and avoid wetting a woolen fabric to a greater extent, as this risks remaining stains.
- If necessary, a foam detergent can also be used for a more thorough cleaning if this is allowed in the fabric's specification.

WOOD

Wood is a living material whose grain from the very beginning has a natural variation in pattern, color tone and luster. The wood is affected by, among other things, the season, heat and humidity. That wood is a living material means:

- Screws need to be re-tightened regularly, at least once a year.
- Solid table tops can naturally warp by up to 0.5%.
- Light from the sun and lighting can cause permanent color and light differences in the surface, so allow the entire wooden surface to be exposed to the same amount of light.

Out of concern for the environment, we paint a large part of our range with water-based surface treatments. This means:

- Spills of coffee and other liquids need to be wiped up immediately.
- For cleaning, hand washing detergent or pH-neutral detergents and lukewarm water are recommended. Wipe off with clean water and wipe dry. Do not use cleaning agents that are alkaline, aggressive, contain abrasives or solvents.
- For disinfection, non-alcohol-based agents are recommended, e.g. Virkon or DAX Alco Free. Alcohol-based agents



must not be used.

NC Nordic Care AB

Box 30 573 35 Tranås Sweden

+46(0)140-38 40 60, info@ncnordiccare.se

ncnordiccare.se