



FUNCTIONAL ARMCHAIR WITH HIGH BACK

FREJA 237

Freja 237 is a functional armchair in birch wood with wheels and footplate. It is stepless and adjustable, for increased function and accessibility. The seat and back have removable upholstery that facilitates washing.

With adjustability controls on both sides of the armchair, it is easy to use and adjust when necessary.

Freja 237 is therefore a good choice for nursing homes and in care and social care.

Freja 237 is labeled with FSC® and Möbelfakta.

DIMENSIONS

Height	112 cm
Width	69 cm
Seat height	48 cm
Seat depth	50 cm
Höjd armledare	61 cm



Any NCS-color available as an option on this product.

CERTIFICATIONS



ADDED VALUE


- Som standard kan fåtöljen beställas klarlackad eller betsad i svart eller vitt

ACCESSORIES

- Går att få i valfri heltäckande kulör mot tillägg
- Kan beställas med tygtäckta armstöd, nackkudde och gummiväv på sits

RECYCLING

- Solid wood
- Removable upholstery



PLASTIC

For wiping, use a mild detergent without solvents or abrasives. Regular dish soap works well.

FABRIC

- Removable and washable fabrics are washed according to washing instructions. These are sewn with a shrink seam, wash before use for optimal fit.
- Vacuuming with a soft nozzle is often sufficient for cleaning.
- Stains should always be removed as quickly as possible. In most cases, wiping with a damp cloth is sufficient, for more difficult stains, a pH-neutral detergent or a foam detergent for professional use can be used.
- Always use white cloths and avoid wetting a woolen fabric to a greater extent, as this risks remaining stains.
- If necessary, a foam detergent can also be used for a more thorough cleaning if this is allowed in the fabric's specification.

WOOD

Wood is a living material whose grain from the very beginning has a natural variation in pattern, color tone and luster. The wood is affected by, among other things, the season, heat and humidity. That wood is a living material means:

- Screws need to be re-tightened regularly, at least once a year.
- Solid table tops can naturally warp by up to 0.5%.
- Light from the sun and lighting can cause permanent color and light differences in the surface, so allow the entire wooden surface to be exposed to the same amount of light.

Out of concern for the environment, we paint a large part of our range with water-based surface treatments. This means:

- Spills of coffee and other liquids need to be wiped up immediately.
- For cleaning, hand washing detergent or pH-neutral detergents and lukewarm water are recommended. Wipe off with clean water and wipe dry. Do not use cleaning agents that are alkaline, aggressive, contain abrasives or solvents.
- For disinfection, non-alcohol-based agents are recommended, e.g. Virkon or DAX Alco Free. Alcohol-based agents must not be used.