



ARMCHAIR WITH TWO SEAT HEIGHTS

ELLINOR 147

Ellinor is a stylish series with a classic design. The series includes chairs and benches in varying sizes and shapes, to make the furniture as inclusive as possible.

Ellinor 147 is the series' standard model with armrests. The chair comes in a classic style with high function and durability, which gives it a wide range of use in public environments.

The Ellinor chairs have a fully upholstered seat with a gap between the seat and the back to facilitate cleaning. As standard, you can get the chair in clear lacquered birch or stained in black or white.

Ellinor is marked with FSC-mix and Möbelfakta.



DIMENSIONS

Height	86 cm
Width	56 cm
Depth	55 cm
Seat height	46 cm
Seat depth	42 cm
Höjd armledare	67 cm




Any NCS-color available as an option on this product.

CERTIFICATIONS



VIEWS



ADDED VALUE

- Large family with armchair, chair, XL-armchair, sofa bench and sofas
- Removable upholstery
- Floating seat on chair, armchair and sofa bench to minimize dirt-collecting nooks and crannies
- Rubber fabric as standard

ACCESSORIES

- Can be stained in any color
- Extra seat height on the armchair and XL-armchair
- Back cushion
- Sliding wheels for the armchair and the XL-armchair

RECYCLING

- Solid wood

NC Nordic Care AB

Box 30 573 35 Tranås Sweden
 +46(0)140-38 40 60, info@ncnordiccare.se
 nc nordiccare.se



- Removable upholstery

NC Nordic Care AB

Box 30 573 35 Tranås Sweden

+46(0)140-38 40 60, info@ncnordiccare.se

ncnordiccare.se

FABRIC

- Removable and washable fabrics are washed according to washing instructions. These are sewn with a shrink seam, wash before use for optimal fit.
- Vacuuming with a soft nozzle is often sufficient for cleaning.
- Stains should always be removed as quickly as possible. In most cases, wiping with a damp cloth is sufficient, for more difficult stains, a pH-neutral detergent or a foam detergent for professional use can be used.
- Always use white cloths and avoid wetting a woolen fabric to a greater extent, as this risks remaining stains.
- If necessary, a foam detergent can also be used for a more thorough cleaning if this is allowed in the fabric's specification.

WOOD

Wood is a living material whose grain from the very beginning has a natural variation in pattern, color tone and luster. The wood is affected by, among other things, the season, heat and humidity. That wood is a living material means:

- Screws need to be re-tightened regularly, at least once a year.
- Solid table tops can naturally warp by up to 0.5%.
- Light from the sun and lighting can cause permanent color and light differences in the surface, so allow the entire wooden surface to be exposed to the same amount of light.

Out of concern for the environment, we paint a large part of our range with water-based surface treatments. This means:

- Spills of coffee and other liquids need to be wiped up immediately.
- For cleaning, hand washing detergent or pH-neutral detergents and lukewarm water are recommended. Wipe off with clean water and wipe dry. Do not use cleaning agents that are alkaline, aggressive, contain abrasives or solvents.
- For disinfection, non-alcohol-based agents are recommended, e.g. Virkon or DAX Alco Free. Alcohol-based agents must not be used.