

FOOTSTOOL

KURBITS 328

Kurbits is a furniture collection that includes a chair, bench, armchair, and coffee table, all in a classic design with generously spacious proportions. The name Kurbits comes from the decorative folk painting tradition of Dalarna – the region that inspired the entire furniture family.

Kurbits footstool features a cushion with a removable cover secured with snap fasteners, making it easy to clean and promoting good hygiene. It is a natural complement to the two Kurbits peg-back armchairs.

The footstool is made from FSC®-certified birch and is certified with Möbelfakta. It is offered as standard in clear lacquer, white, or black, and is also available in any custom color on request.

Design: Helene Tiedemann

DIMENSIONS

Height	43 cm
Width	63 cm
Depth	39 cm

Any color available as an option on this product.

CERTIFICATIONS

FSC www.fsc.org FSC® C010544 The mark of responsible forestry

VIEWS



MÖBELFAKTA

ADDED VALUE

- Removable upholstery
- Tested for public use and meets the requirements for durability & safety, set forth in the following standard, EN 16139

ACCESSORIES

- Frame in clear lacquer, white or black (standard)
- Frame in any color (special)
- Choice of fabric

REUSE

- Solid wood
- Removable upholstery

NC Nordic Care AB
Box 30 573 35 Tranås Sweden
+46(0)140-38 40 60, info@ncnordiccare.se
ncnordiccare.se

- Replaceable padding

NC Nordic Care AB
Box 30 573 35 Tranås Sweden
+46(0)140-38 40 60, info@ncnordiccare.se
ncnordiccare.se

FABRIC

- Removable and washable fabrics are washed according to washing instructions. These are sewn with a shrink seam, wash before use for optimal fit.
- Vacuuming with a soft nozzle is often sufficient for cleaning.
- Stains should always be removed as quickly as possible. In most cases, wiping with a damp cloth is sufficient, for more difficult stains, a pH-neutral detergent or a foam detergent for professional use can be used.
- Always use white cloths and avoid wetting a woolen fabric to a greater extent, as this risks remaining stains.
- If necessary, a foam detergent can also be used for a more thorough cleaning if this is allowed in the fabric's specification.

WOOD

Wood is a living material whose grain from the very beginning has a natural variation in pattern, color tone and luster. The wood is affected by, among other things, the season, heat and humidity. That wood is a living material means:

- Screws need to be re-tightened regularly, at least once a year.
- Solid table tops can naturally warp by up to 0.5%.
- Light from the sun and lighting can cause permanent color and light differences in the surface, so allow the entire wooden surface to be exposed to the same amount of light.

Out of concern for the environment, we paint a large part of our range with water-based surface treatments. This means:

- Spills of coffee and other liquids need to be wiped up immediately.
- For cleaning, hand washing detergent or pH-neutral detergents and lukewarm water are recommended. Wipe off with clean water and wipe dry. Do not use cleaning agents that are alkaline, aggressive, contain abrasives or solvents.
- For disinfection, non-alcohol-based agents are recommended, e.g. Virkon or DAX Alco Free. Alcohol-based agents must not be used.

NC Nordic Care AB
Box 30 573 35 Tranås Sweden
+46(0)140-38 40 60, info@ncnordiccare.se
ncnordiccare.se