



DIMENSIONS

Height	120 cm
Width	65 cm
Depth	80 cm
Seat height	47 cm
Seat depth	46 cm



Any color available as an option on this product.

CERTIFICATIONS



VIEWS



ARMCHAIR

AMULETT 730

Amulett with covered frame is available in two variants: 730, which is fixed, and 735, which is adjustable.

Amulett family consists of inclusive and embracing armchairs and a footstool, designed to perform in environments with very high demands on comfort, hygiene, and safety. The responsive design language, combined with softly shaped armrests and natural materials, creates a strong tactile experience. Amulett is generous yet compact and easy to place. For optimal hygiene, Amulett features removable upholstery and a gap between the seat, back, and frame, helping to prevent dirt and bacteria from building up. Amulett is tested for a user weight of up to 160 kg in accordance with Möbelfakta requirements.

Amulett is well suited for public environments where accessibility and comfort are important, such as care and nursing homes.

The armchair is made of FSC®-certified birch and oak and is certified with Möbelfakta. It is offered as standard in clear lacquer, white, or black, and is also available in any custom color on request.

Design: Studio JOOY



ADDED VALUE


- Armchair with demands on comfort, hygiene and security
- Generous, neat and easily placed
- Inclusive and embracing
- Gap between seat, back and frame for best hygiene
- Removable upholstery
- Tested for public use and meets the requirements for durability & safety, set forth in the following standard, EN 16139
- Tested for 160kg

NC Nordic Care AB

Box 30 573 35 Tranås Sweden

+46(0)140-38 40 60, info@ncnordiccare.se

ncnordiccare.se




ACCESSORIES

- Frame in FSC®-certified birch or oak
- Frame in clear lacquer, white or black (standard)
- Frame in any color (special)
- Choice of fabric
- Rubber fabric/hospital fabric
- Wheel
- Footrest

REUSE

- Solid wood
- Removable upholstery



LEATHER

If you take care of the leather in the right way, it will become more beautiful over the years.

- Leather is heat sensitive. Therefore, direct sunlight and close contact with heating elements should be avoided.
- Vacuum the furniture to remove loose dirt and dust.
- Wipe the leather with a slightly damp cloth and a mild soapy solution can be used for cleaning.
- Water-based leather care products extend the lifespan.

FABRIC

- Removable and washable fabrics are washed according to washing instructions. These are sewn with a shrink seam, wash before use for optimal fit.
- Vacuuming with a soft nozzle is often sufficient for cleaning.
- Stains should always be removed as quickly as possible. In most cases, wiping with a damp cloth is sufficient, for more difficult stains, a pH-neutral detergent or a foam detergent for professional use can be used.
- Always use white cloths and avoid wetting a woolen fabric to a greater extent, as this risks remaining stains.
- If necessary, a foam detergent can also be used for a more thorough cleaning if this is allowed in the fabric's specification.


WOOD

Wood is a living material whose grain from the very beginning has a natural variation in pattern, color tone and luster. The wood is affected by, among other things, the season, heat and humidity. That wood is a living material means:

- Screws need to be re-tightened regularly, at least once a year.
- Solid table tops can naturally warp by up to 0.5%.
- Light from the sun and lighting can cause permanent color and light differences in the surface, so allow the entire wooden surface to be exposed to the same amount of light.

Out of concern for the environment, we paint a large part of our range with water-based surface treatments. This means:

- Spills of coffee and other liquids need to be wiped up immediately.
- For cleaning, hand washing detergent or pH-neutral detergents and lukewarm water are recommended. Wipe off with clean water and wipe dry. Do not use cleaning agents that are alkaline, aggressive, contain abrasives or solvents.
- For disinfection, non-alcohol-based agents are recommended, e.g. Virkon or DAX Alco Free. Alcohol-based agents



must not be used.